

# CG-SRIII Attaching instruction of the sheet basket






Attach the sheet basket to prevent the cut (plotted) result from being stained.

**Important!** ■ This document describes the procedure based on CG-100SRIII illustration. Attach this following the same procedure for other models.

## Accessories


Using the followings in the package, attach the sheet basket.

In case the supplies quantity differs or having a problem with the item, contact your delivery agent or us directly.

<p><b>Basket Bracket x 2</b></p> 	<p><b>Bracket bar x 4</b></p> 	<p><b>Sheet basket bar x 2</b></p> 	<p><b>Sheet basket x 1</b></p> 
<p><b>Screw x 8</b></p> 			


## Attaching instruction

- 1 Attach the basket bracket on the leg. (right and left)**




- 2 Remove the cap of the attached basket bars (x 4) (only one side).**

Remove the cap with the hexagon wrench accessories of main unit.




- 3 Insert the basket bar into the attaching hole.**

Insert the side whose cap was removed into the attaching hole.




- 4 Attach the cap removed in the Step 2 on the basket bar.**

Attach it on four bars in the same way.



- 5 Attach the pipe joint on the basket bar.**

- Use the upper basket bar on right and left for the sheet basket in front, and use the lower basket bar for the sheet basket in rear.
- Attach the pipe joint each for the basket bar at front and rear.




---

## 6 Insert the pipes (Sheet basket bar x 1) into the attached fabric

**重要!**


- There are two pipes(sheet basket bar) to be used for the sheet basket. Attach the pipe joint each for the basket bar at front and rear.
- Here, insert only two pipes. If you insert all three pipes, the pipe may hit this device when attaching the rear side sheet basket in the Step 8 and it may cause the damage.



---

## 7 Attach the pole on the front side basket bar.


Insert the pole put through the fabric in the Step 6 on the pipe joint attached on the basket bar.




---

## 8 Pass the fabric to the rear side.

Send the fabric to the rear side as indicated.



- 
- 9** Insert the remaining pipe (sheet basket bar x 1) into the pipe inserting part and attach it on the rear side basket bar.








# CG-SRIII シートバスケットの取り付け方

カット ( 作図 ) 成果物を汚さないようにするために、シートバスケットを取り付けてください。

**重要!** ■本書では、CG-100SRIII のイラストをもとに説明しています。他のモデルの場合も、同様の手順で取り付けます。


## 使用する部品

梱包箱の以下の物を使用して、シートバスケットを取り付けます。数量が違っていたり異常があった場合は、販売店または弊社営業所までご連絡ください。

<p>バスケット ブラケット x 2</p> 	<p>ブラケットバー x 4</p> 	<p>シートバスケット バー x 2</p> 	<p>シートバスケット x 1</p> 
<p>ネジ x 8</p> 			


## 取り付け方法

- 1** 本機の脚にバスケットブラケットを取り付ける (左右)




- 2** 付属品のバスケットバー(4本)のキャップ(片側のみ)を取り外す

六角レンチ (本体付属品) を使ってキャップを外します。




- 3** バスケットバーを取り付け穴に差し込む  
キャップを外した側を取り付け穴にさし込んでください。




- 4** 手順2で外したキャップをバスケットバーに取り付ける

4本同様に取り付けます。




- 5** パイプジョイントをバスケットバーに取り付ける

- 左右の上側のバスケットバーを手前側のシートバスケット用、下側のバスケットバーを背面側のシートバスケット用に使います。
- パイプジョイントは、手前側、背面側のバスケットバーに1箇所取り付けてください。(左右両方)




## 6 付属の布にパイプ(シートバスケットバー:1本)を差し込む

- 重要!** ■シートバスケットに使用するパイプ(シートバスケットバー)は2本あります。ここでは先に、手前側のパイプを差し込みます。
- ここでは、パイプを1本だけ差し込んでください。2本のパイプをすべて差し込むと、手順8からの作業で背面側のシートバスケットを取り付けるときにパイプが本機に当たり、破損の原因となります。




## 7 手前側のバスケットバーにパイプを取り付ける

手順6で布に通したパイプをバスケットバーに取り付けたパイプジョイントにはめ込みます。



## 8 布を背面側に通す

図のようにして、布を背面に送ります。



- 
- 9** 残りのパイプ(シートバスケットバー: 1本)を背面シートバスケット用のパイプ差し込み部に差し込み、背面バスケットバーに取り付ける

